



TOOLING CONNECTION FOR DX SERIES MULTICYLS


CONNECTION PROCEDURE




MINIMUM DISTANCE BETWEEN MOUNTING PLATE & TOOLING WITH FLEXIBLE COUPLER




MINIMUM DISTANCE BETWEEN MOUNTING PLATE & TOOLING WITHOUT FLEXIBLE COUPLER



EAC-1000 FLEXIBLE COUPLER



DC-6003/6004 DIE CONNECTOR SET



MULTICYL [®] _{INC.}

The SPEED of AIR with the POWER of HYDRAULICS

MULTICYL [®] Inc.

640 Hardwick Road, Unit 5
Bolton, Ontario
Canada L7E 5R1
(905) 951-0670
FAX (905) 951-0672